



**Ball Aerospace
& Technologies Corp.**

1600 Commerce St., Boulder, CO 80301 (303) 939-4373 FAX: (303) 939-6263
Reply to: P. O. Box 1062, Boulder, CO 80306-1062

9 October 2003
Defsys.03.SMF.043

Northrop Grumman Corporation
Space Technology
One Space Park, M/S R10/2077G
Redondo Beach, CA 90278

Attention: Ms. Fayda Ayache
Subcontracts Manager

Subject: Request to Disclose OMPS Related Data

Reference: Subcontract 64584DDQ2S

In accordance with referenced subcontract, Ball Aerospace respectfully requests your authorization our subcontractor, Raytheon, to present OMPS related data at the Fall 2003 AGU conference. This specific request is for the attached presentation "*The Ozone Mapping and Profiler Suite: The Extension of the BUV Technique to Meet Future Ozone Measurement Requirements*".

The presentation is due no later than 1 DEC 2003 and would appreciate your decision before that time. Please contact me at 303/939-4373 or e-mail at sflahert@ball.com if I can provide any additional information.

Sincerely,

A handwritten signature in black ink, appearing to read "Sean Flaherty", with a stylized flourish at the end.

Sean M. Flaherty, CPCM
Contracts Manager
Ball Aerospace & Technologies Corp.

Space & Electronics Clearance Request for Public Release of Information

NORTHROP GRUMMAN

Space Technology

TECHNOLOGY
CLEARANCE OFFICE ONLY

**ALLOW 3-6 WEEKS FOR
CUSTOMER/GOVERNMENT
REVIEW**

- ☐ ABSTRACT /SUMMARY ☐ MEDIA MATERIALS
☒ TECHNICAL PAPER ☐ ADVERTISEMENT
☐ ORAL PRESENTATION ☐ BROCHURE
☐ NEWS RELEASE ☐ AUDIOVISUAL
☐ EXHIBIT DISPLAY ☐ INTERNET MATERIAL

1. AUTHOR(S) Raytheon as subcontractor to Ball Aerospace & Technologies Corp. (BATC)		CCC M294	BLDG R10	MAIL STA 2744	PHONE X.46806	PROCESS ORGANIZATION /PROGRAM P&SCM/NPOESS
2. TITLE OF MATERIAL The Ozone Mapping and Profiler Suite: The Extension of the BUUV Technique to Meet Future Ozone Measurement					3. AUTHOR(S) DEADLINE 1 DEC 2003	
4. <input type="checkbox"/> COMPANY FUNDED <input type="checkbox"/> NON-GOVERNMENT CONTRACT <input checked="" type="checkbox"/> GOVERNMENT CONTRACT		CLASSIFICATION OF MATERIAL <input checked="" type="checkbox"/> UNCLASSIFIED <input type="checkbox"/> U.S. ONLY <input type="checkbox"/> SECRET			5. SESSION CLASSIFIED YES <input type="checkbox"/> NO <input checked="" type="checkbox"/> DISTRIBUTE OUTSIDE U.S.? YES <input type="checkbox"/> NO <input checked="" type="checkbox"/>	
6. PURPOSE: FOR MEETINGS / CONFERENCES LIST NAME, SPONSOR, DATE, LOCATION. FOR PUBLICATIONS, LIST JOURNAL, PUBLISHER, PROPOSED DATE. To allow subject presentation to be provided to the AGU Fall meeting.						
7. DOES THE SUBMITTED MATERIAL DESCRIBE AN INVENTION, SOFTWARE OR CONCEPT THAT IS POTENTIALLY PATENTABLE? IF DEVELOPED UNDER IR&D, LIST PROJECT NUMBER: YES <input type="checkbox"/> NO <input checked="" type="checkbox"/>						
8. IF YES TO 7, HAS AN INVENTION DISCLOSURE, FORM 125, BEEN FILED WITH LAW DEPARTMENT? IF ANSWER IS YES, LIST DISCLOSURE DOCKET NUMBER: PATENT NUMBER: YES <input type="checkbox"/> NO <input type="checkbox"/>						
9. WAS ANY WORK DESCRIBED DONE UNDER CONTRACT? (IF SO, COMPLETE 10, 11, AND 12.) YES <input checked="" type="checkbox"/> NO <input type="checkbox"/>						
10. CONTRACT NUMBER: F0470-02-C-0502 SALES NUMBER: 01E163						
11. PROCURING AGENCY / PRIME CONTRACTOR: NPOESS Integrated Program Office (IPO)/Northrop Grumman Space Technology (NGST)						
12. CUSTOMER TECHNICAL MONITOR(S): Lt. Curtis Stutz PHONE NUMBER(S): (301) 713-4783						
13. AUTHOR'S SIGNATURE (ON BEHALF OF AUTHORS) SIGNATURE _____ TYPED NAME: BATC DATE _____						
14. ORGANIZATION/PROGRAM DESIGNEE SIGNATURE _____ TYPED NAME: F. Ricker or Designee DATE _____				15. BUSINESS DEVELOPMENT (REQUIRED FOR NEWS RELEASES AND ADVERTISEMENTS ONLY) SIGNATURE _____ TYPED NAME: _____ DATE _____		
16. LAW DEPARTMENT (REQUIRED IF ANSWER TO 7 OR 8 ABOVE IS "YES") SIGNATURE _____ TYPED NAME: _____ DATE _____				17. EXPORT (AUDIENCE MAY INCLUDE NON-U.S.PERSONS) SIGNATURE _____ TYPED NAME: BATC DATE _____		
18. SECURITY SIGNATURE _____ TYPED NAME: N. Gimma DATE _____				19. TECHNOLOGY CLEARANCE OFFICE SIGNATURE _____ TYPED NAME: S. L. Cohen DATE _____ CLEARANCE: <input type="checkbox"/> APPROVED <input type="checkbox"/> APPROVED W/AMENDMENTS <input type="checkbox"/> DENIED <input type="checkbox"/> LIMITED APPROVAL		

Space & Electronics Clearance Request for Public Release of Information


NORTHROP GRUMMAN

Space Technology

20. INSTRUCTIONS / REMARKS

Concurrence:

Nann Gimma
NPOESS Security Manager




The Ozone Mapping and Profiler Suite: The Extension of the BUV Technique to Meet Future Ozone Measurement Requirements

Colin J. Seftor, Jack C. Larsen
Raytheon Information Technology and Scientific Services

Quinn Remund, Juan V. Rodriguez
Ball Aerospace & Technologies Corp.

Lawrence E. Flynn
NOAA / NESDIS

Ernest Hilsenrath
NASA Goddard Space Flight Center




Introduction



First scheduled flight is on the NPOESS Preparatory Project (NPP) mission in 2006

Both the nadir mapper and nadir/limb profiler system will provide measurements with higher accuracy and precision than heritage


- The Ozone Mapping and Profiler Suite (OMPS) is the next-generation ozone monitoring system designed to replace both the Total Ozone Mapping Spectrometer (TOMS) and Solar Backscatter Ultraviolet Spectrometer/2 (SBUV/2) systems
 - OMPS will fly onboard the National Polar-orbiting Operational Environmental Satellite System (NPOESS)
- The OMPS nadir mapper will extend the nearly 3 decade data set of total column ozone measurements taken by the TOMS series of instruments
- The OMPS nadir profiler/limb profiler system will extend the nearly 3 decade data set of ozone profiler measurements taken by the SBUV, SBUV/2 series of instruments




Nadir Sensor Consists of a Mapper and a Co-Boresighted Profiler



- Single pushbroom telescope
- Two grating spectrometers
 - Each spectrometer has a CCD detector array
 - Both sample spectrum at 0.42 nm, 1 nm FWHM end-to-end resolution
- Calibration stability maintained by periodic solar observations using dual reflective diffusers
- Electronics
 - CCD preamplifier electronics in sensor housing
 - Main electronics box
 - ♦ Analog-to-digital conversion
 - ♦ On-orbit pixel corrections





Nadir total column has 300-380 nm coverage
Nadir profiler has 250-310 nm coverage




Nadir Sensor Fields of View



- **Total Column:**
 - 110° cross-track FOV, 0.27° along-track slit width, 8.5° FOV curvature on Earth
 - 35 cross-track bins: 3.35° (50 km) at nadir, 2.84° at $\pm 55^\circ$
 - 50 km along-track resolution at nadir (7.6 sec reporting period)
- **Nadir Profile:**
 - 16.6° cross-track FOV, 0.26° along-track slit width
 - One 250 km cell cross-track
 - 250 km along-track resolution (38 sec reporting period)






OMPS Total Column Algorithm Builds on the Strong Foundation of TOMS Version 7




- **Version 7 TOMS algorithm retrieves total column ozone with close to threshold performance**

- Uses logarithm of the ratio of backscattered radiance to incident solar irradiance, N
- Assumes change in N value linear with wavelength
- Uses a wavelength triplet



- **Enhancements bring OMPS algorithm performance to within NPOESS requirements**
 - Multiple triplets
 - Temperature-insensitive wavelengths
 - Temperature and ozone profile corrections
 - Tropospheric residual




Limb Sensor Measures Limb Scatter in the Ultraviolet, Visible, and Near-Infrared




- **Six apertures, three slits, one prism, one focal plane**
 - Two types of raw data records corresponding to different integration times
 - Bandpass varies from 2.5 to 50 nm over 290-1000 nm
- **Calibration stability maintained by periodic solar observations using dual transmissive diffusers**
- **Electronics similar to nadir Limb scatter flight heritage:**
 - Solar Mesosphere Explorer (SME)
 - Shuttle Ozone Limb Sounding Experiment / Limb Ozone Retrieval Experiment (SOLSE/LORE) on STS-87 (December 1997)

Limb Radiance Profiles for M325 Ozone Profile, SZA=40°




Remote Sensing of Limb-Scattered Solar Radiation Shares Atmospheric Radiative Transfer Physics, Calibration Techniques with OMPS Nadir Sensor




OMPS Limb Sensor Stares at the Limb Along the Satellite Track




Photo from GSFC's SOLSE/LORE Shuttle flight



OMPS limb sampling
(worst case pointing limit)



- OMPS limb sensor has 3 slits separated by 4.25 degrees
- 38 second reporting period: 250 km along track
- 130 km (2.23 degree) vertical FOV at limb for 0-60 km coverage plus offsets (pointing, orbital variation, Earth oblateness)





Optical Design



- **Prism spectrometer**

- 290-1000 nm
- Spectral resolution matched to ozone absorption features
- Polarization compensators minimize sensor polarization sensitivity
- Low stray light
- High efficiency







Dynamic range covered with multiple images and integration times.



- Cross-track samples obtained with 3 separate apertures/telescopes.
- Scene dynamic range coverage.
 - 2 Separate apertures in each telescope produce 2 optical gains.
 - 2 Interleaved integration times produce 2 electronic gain levels.
 - Total of 4 gain levels provide coverage of scene dynamic range with good SNR.
 - ♦ High-Gain long integration Low Gain (Dim)
 - ♦ Low-Gain long integration
 - ♦ High-Gain short integration High Gain (Bright)
 - ♦ Low-Gain short integration
- All six spectra captured with a single focal plane







OMPS Limb Sensor Spectral Coverage is 290-1000 nm



- Middle and near-ultraviolet channels provide coverage from 28 to 60 km
- Visible channels including 602 nm provide coverage from tropopause to 28 km
- Additional channels between 350 and 1000 nm provide characterization of Rayleigh and aerosol scattering background






SOLSE/LORE Algorithm Provides Strong Foundation for OMPS Profile Ozone Retrieval




- **Forward model radiative transfer code developed by U. of Arizona (Ben Herman and Dave Flittner)**
 - Multiple scattering solution in a spherical atmosphere
 - ◆ Molecular and aerosol scattering
 - ◆ Ozone absorption
 - Includes polarization
 - Provides high accuracy with minimal computation
- **Inversion code developed by Code 916 and U. of Arizona**
 - Retrieval performed using optimal estimation algorithm
- **Enhancements by OMPS team include:**
 - Additional ozone channels
 - Aerosol extinction profile retrievals at non-ozone-absorbing wavelengths
 - Bulk neutral density retrievals
 - Effective surface reflectance and cloud fraction retrievals
 - Nadir profiler measurements used as first guess and for altitude registration of the limb profile measurement




OMPS Includes an Algorithm That Uses Data from the Cross-track Infrared Sounder (CrIS) to Obtain Ozone Column Measurements



- CrIS band 1 (635 - 1095 cm^{-1}) contains temperature, ozone, and surface information, along with some information about H_2O
- CrIS EDRs (Temperature, pressure and water vapor profiles) are used in conjunction with CrIS SDRs (950 - 1095 cm^{-1}) to retrieve ozone
- Emphasis is on polar night, measurements in the South Atlantic Anomaly (SAA)
 - Retrievals in SAA will help to validate performance of nadir total column CCD and, hence, retrievals in this area



IMG Data from Mar/Apr 1997
Courtesy of Ryoichi Imasu (University of Tokyo)




Other Products Also Possible from OMPS Nadir Sensors



Product	Nadir Total Column	UV/VIS Limb	Nadir Profile	IR Total Column	Algorithm	Product	Spectral Range (nm)	Comment
Nadir Total Column O ₃	E					H ₂ CO	336-357	Can detect down to 1.3×10^{15} mol / cm ²
UV/VIS Limb O ₃ Profile			E			BrO	345-369	Can detect
Nadir O ₃ Profile						OcIO	354-383	Can detect in polar vortex
Cloud Fraction (Reflectivity)						NO ₂	340-380	Can detect from biomass burning, urban pollution
Visible Surface Reflectivity						SO ₂	313-321	Detection better than GOME
Aerosol Index								
Volcanic SO ₂								
Aerosol Profile								
Neutral Number Density Profile								
Temperature Profile								
Cloud Height								
UV Surface Reflectivity								

	EDR Product
	Algorithm Input Generated Internally by OMPS
	Algorithm by-products available as P ³
	Algorithm Input Supplied by External EDR (preferred) or Climatological Database

A7785 161



Conclusion



- **Ozone Mapping and Profiler Suite (OMPS) will provide:**
 - Global mapping of total column every 24 hours
 - High-vertical-resolution limb ozone profiles
 - Along-track vertical profile, continuing SBUV-SBUV/2 record
- Engineering Demonstration Units built and tested
- First flight will be on NPP in 2006
- First NPOESS flight planned for 2011

